

IC Requirements:

Licence-exempt radio apparatus

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed the specified gain by the manufacturer declared.
- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so.
- The device complies with RF specifications when the device used at 5mm from your body. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.
- DO NOT operate the transmitter in areas that are sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.

Avoid Choking Hazard



Small Parts. Not for children under 3 years.

Protect your hearing:



- Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before adding headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear
- Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss



Note: Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.

Avoid Burns



Antennas

- Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

Batteries (If appropriate)

- When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns. Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects

Long transmission

- When the transceiver is used for long transmissions, the radiator and chassis will become hot.

Safety Operation



Forbid

- Do not use charger outdoors or in moist environments, use only in dry locations/conditions.
- Do not disassemble the charger, that may result in risk of electrical shock or fire.
- Do not operate the charger if it has been broken or damaged in any way.
- Do not place a portable radio in the area over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates.

To reduce risk

- Pull by the plug rather than the cord when disconnecting the charger.
- Unplug the charger from the AC outlet before attempting any maintenance or cleaning.
- Contact Reteless for assistance regarding repairs and service.
- The adapter shall be installed near the equipment and shall be easily accessible
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Adapter shall be installed near the equipment and shall be easily accessible.
- The plug considered as disconnect device of adapter.
- The operating temperature of the EUT can't exceed the specified range.

Approved Accessories



- This radio meets the RF exposure guidelines when used with the Reteless accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.
- For a list of Reteless-approved accessories for your radio model, visit the following website: <http://www.Reteless.com>

RETELESS

TD123

Wireless Calling Receiver User Manual

EU Importer

Name: Germany Retevis Technology GmbH
Address: Uetzenacker 29,38176 wendeburg

Henan Eshow Electronic Commerce Co., Ltd

Add: 7/F, Sanjiang Building, No.170 Nanyang Road, Huiji District, Zhengzhou, Henan, China

Restore factory value after power on

Plug the power in the box into the socket, and a small head on the other end of the power supply is inserted into the DC hole of the main engine. Short press the setup "■" button, "F1" will appear on the screen, press the up "▲" key to turn to F4, press the setup "■" key once, the host will appear 0001, the unit digital tube flickering. Press the down "▼" key to make the screen display as "0000", and then long press the setup "■" Key until the number on the screen is jumping automatically, which means that the factory value is being restored. After emptying, the host screen back to the standby mode.

The caller registration and single caller delete F4

Add caller:

1. When the host is in standby mode, press the setup "■" button, and the host screen will show " F1 ", press the up "▲" key to turn to " F4 " ;
2. Press the setup "■" button once, and " 0001 " will appear on the display screen ;
3. Use the up "▲" or down "▼" key shift to select the number to register ;
4. Press the caller that needs to be registered once, there's a short voice prompt and the number displayed on the screen will automatically jump to the next one to register the next caller ;
5. After caller added, press back "●" key once to return to standby state. (NOTE: if there is a red dot "·" in the middle of the code on the digital tube, that mean the number has been registered by other caller, you need to delete it before new registration of the same number.)

Delete single caller

1. When the host is in standby mode, press the setup "■" button, and the host screen will show " F1 ", press the up "▲" key to turn to " F4 " ;
2. Press the setup "■" button once, and " 0001 " will appear on the display screen ;
3. Use the up "▲" or down "▼" key shift to select the number to delete ;
4. Long press the setup "■" button for about two seconds will be OK
5. After caller deleted, press back "●" key once to return to standby state.

Set the prompt music F1

Press setup "■" button once and the " F1 " will appear on the screen. Short press setup "■" button to enter the options menu, press up "▲" or down "▼" key to select the prompt music from 0-4

- 0 ding-dong and voice prompt of the room+bed call
- 1 Ding-dong
- 2 Airport prompt
- 3 Di...
- 4 Alarm prompt

Cycle time setting F2

1. Press setup "■" button once to enter the setting menu, the screen will display " F1 ", and press up "▲" key to " F2 " ;
2. Press setup "■" button to enter the selection menu, and press up "▲" or down "▼" key to set the cycle time.
In this system, the cycle time is set within 0-99 seconds, when the cycle time is " 00 ", the system will not automatically jump scroll display
3. Press back "●" key once to return to standby state.

Automatically cleaning call information time setting F3

1. Press setup "■" button once to enter the setting menu, the screen will display " F1 ", and press up "▲" key to " F3 " ;
2. Press setup "■" button to enter the selection menu, and press up "▲" or down "▼" key to set the automatic cleaning time. The system will clear the call information after receiving it for a certain time ;
The system automatically eliminate time with a setting range of 0-9999 seconds. If you set it as " 00 ", the call information will not be cleaned automatically
3. Press back "●" key once to return to standby state.

Set the prompt music length F5

1. Press setup "■" button once to enter the setting menu, the screen will display " F1 ", and press up "▲" key to " F5 " ;
2. Press setup "■" button to enter the selection menu, and press up "▲" or down "▼" key to set the length of prompt calls
In this system, the length of prompt calls is set within 0-99 times, when you set it as " 00 ", The host will be on the mute mode.
3. Press back "●" key once to return to standby state.

Special menu function F6

This menu as a function is used in special circumstances. Generally, it is recommended to select "0" in this menu instead of other values. (customized according to requirements)

Time setting F7


1. Press setup "■" button once to enter the setting menu, the screen will display " F1 ", and press up "▲" key to " F7 " ;
2. Press setup "■" button to enter the sub-menu setting time, then press the setup "■" button to shift, and press up "▲" or down "▼" key to select the current time
- 3 Press back "●" key once to return to standby state.

Volume

When the host is in standby mode and time is displayed, select up "▲" or down "▼" key to adjust volume.

Note: If the call information is displayed on the screen, the volume cannot be adjusted, it is necessary to press the back "●" button to return to the standby state for volume adjustment.

Warnings



This radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage.

All Reteless radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of the radios. These instructions are important because they inform users about RF energy exposure and provide simple procedures on how to control it.

Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: <http://www.who.int/en/>

Local Government Regulations

When radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user awareness information. Your Reteless radio has a RF Exposure Product Label. Also, your Reteless user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

Radio License (if appropriate)

Governments keep the radios in classification, business radios operate on radio frequencies that are regulated by the local radio management departments (FCC, ISED, OFCOM, ANFR, BFTK, Bundesnetzagentur...). To transmit on these frequencies, you are required to have a license issued by them. The detailed classification and the use of your radios, please contact the local government radio management departments.
Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services.
Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

FCC Requirements:

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Requirements:

- (Simple EU declaration of conformity) Henan Eshow Electronic Commerce Co.,Ltd declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU; the full text of the EU declaration of conformity is available at the following internet address: www.reteless.com.

Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.

